MAGIC TBR

Tunnel Break-In Rebroadcast System for DAB

Hardware and Software Manual



A publication of AVT Audio Video Technologies GmbH

Nordostpark 91 90411 Nuerberg Germany Phone +49-911-5271-0 Telefax +49-911-5271-100

© AVT Audio Video Technologies GmbH All Rights reserved. Reproduction in whole or in parts is prohibited without the written consent of AVT GmbH. Subject to changes.

Release date: November 18

CONTENT

1	Int	troduction	7
	1.1	Conventions	7
	1.2	Safety	7
	1.3	General Safety Requirements	8
	1.4	Construction	9
	1.5	Functionality	10
2	Pu	utting MAGIC TBR into operation	13
	2.1	Mounting	13
	2.2	Connection to the main voltage	13
	2.3	Earthing of the system	14
	2.4	Operational elements of the front keypad and display	15
	2.5	Front status LEDs	15
	2.6	Wiring of the system	16
	2.7	Basic configuration via front panel	17
3	Th	ne web interface of MAGIC TBR	19
	3.1	SETTINGS - Step-by-step configuration of the system	20
	3.1	.1 Operation mode configuration	21
	3.1	.2 Break-In configuration	22
	3.1	.3 Audio Input configuration	25
	3.1	.4 Audio Output (Monitoring)	26
	3.1	5 General settings	27
	3.1	.6 LAN settings	
	3.1	.7 VLAN settings	29
	3.1	.8 SNMP settings	
	3.1	.9 Triggering of a Break-In via SNMP	35
	3.2	ADMINISTRATION of the system	37
	3.2	.1 Registration	
	3.2	.2 File System	38
	3.2	.3 Firmware Download	39
	3.2	.4 System Panel	40
	3.2	5 Restart Device	40
	3.3	EXTRAS – Maintenance functions	41
	3.3	.1 System Monitor	41
	3.3	.2 Protocol File Viewer	44
	3.3	.3 Detailed Ensemble Information	45
	3.3	.4 About	46
	3.3	.5 Login/Logout	46

4	In	terfac	es 49	
	4.1	LAN	1/2 Interface	
	4.2	TTL/I	Relay Interface	
	4.3	Audi	o Interfaces	
	4.3	.1	Analogue Inputs/Outputs	
	4.3	.2	Phones Interface	
	4.3	.3	Digital AES/EBU Audio Interfaces52	
	4.4	RF IN	/RF OUT/GPS IN	
	4.5	Clock	1/Clock 2 Interfaces	
5	Te	echnica	al Data	
6	G	eneral		
	6.1	Orde	r numbers	
	6.2	Scop	e of delivery	
	6.3	Decla	aration of conformity	
7	Se	ervice	Information	
	7.1	Softv	vare and Firmware Updates59	
	7.2	Supp	ort	
	7.3	Repa	irs	
8	Li	st of Fi	gures	
9	Li	st of T	ables	
10) In	dex		

1 INTRODUCTION

MAGIC TBR System is a compact and cost-efficient solution for the DAB tunnel provisioning. A major feature of the system – as requested in the EU Tunnel Directive 2004/54/EC – is the break-in possibility in case of emergencies or also for purely informative announcements.

1.1 Conventions

In this manual the following conventions are used as text markers:



The TIP symbol marks information which facilitates the operation of the system in its daily use.



The Note symbol marks general notes to observe.



The **Attention** symbol marks very important advice that is absolutely to observe. In case of non-observance malfunctions and even system errors are possible.

1.2 Safety

The unit described has been designed to the latest technical parameters and complies with all current national and international safety requirements. It operates on a high level of reliability because of long-term experience in development and constant and strict quality control in our company.

In normal operation the unit is safe.

However - especially if daily routine and technical errors coincide - some potential sources of danger for person, material and optimal operation remain.

This manual therefore contains basic safety instructions that must be observed during configuration and operation. It is essential that the user reads this manual before the system is used and that a current version of the manual is always kept close to the equipment.

1.3 General Safety Requirements

To keep the technically unavoidable residual risk to a minimum, it is absolutely necessary to observe the following rules:

- Transport, storage and operation of the unit must be under the permissible conditions only.
- Installation, configuration and disassembly must be carried out only by trained personal on the basis of the respective manual.
- The unit must be operated by competent and authorised users only.
- The unit must be operated in good working order only.
- Any conversions or alterations to the unit or to parts of the unit (including software) must be carried out by trained personnel authorised by the manufacturer. Any conversions or alterations carried out by other persons lead to a complete exemption of liability.
- Only specially qualified personnel are authorised to remove and override safety measures, and to carry out the maintenance of the system.
- External software is used at one's own risk. Use of external software can affect the operation of the system.
- Use only tested and virus-free date carriers.

1.4 Construction

The functions of **MAGIC TBR** are implemented in a single 19" x 2U unit which is designed for mounting in 19" racks. The front keypad and display of the system allow a basic configuration of the most important parameters like IP address, operating mode etc. Additionally, status information can be displayed via five LEDs. For monitoring purposes, a Phones interface with a 6.3 mm jack is available.



Figure 1: MAGIC TBR Front View

For high reliability the systems have two integrated redundant wide area power supplies. By default, a system can handle one Ensemble. Optionally, a second module can be equipped to use two independent Ensembles.



Figure 2: MAGIC TBR Rear View

1.5 Functionality

MAGIC TBR is implemented on a signal processor-based hardware platform which is assembled in an optimised way and achieves best values in terms of power consumption and reliability. The standard system has a demodulator/modulator module for one Ensemble. If required, the system can be equipped with a further module for a second Ensemble. Both Ensembles are completely independent from each other – a separate break-in is also possible. For the break-in function per ensemble three encoders are permanently running: one DAB+ and two DAB Encoder allow you to replace all Audio service in any configuration regarding bitrate, sampling frequency etc. The break-in signal can be monitored via a Monitoring Decoder.

Repeater and Remodulator Function

In the standard operation mode, the system functions as classic **Repeater** (see Figure 3). The DAB Ensemble is received by an antenna outside the tunnel, is filtered digitally and processed. Via the tunnel antenna the signal is broadcasted again. A GPS signal is not required for this function. However, inputs are available for future extensions.

Depending on local situations (e.g. bad reception conditions) it can be helpful to use the system permanently in **Remodulator** mode (see Figure 4). This mode can also be used during configuration to adjust and optimise the antenna signals at a tunnel entry.



Figure 3: Repeater Mode

Voice Break-In Function

During the repeater operation the received Ensemble is analysed permanently to always have the current Multiplex Configuration Information (MCI) available – even after reconfigurations.

In case of a necessary voice break-in all DAB and DAB+ Audio sub channels are automatically replaced by the emergency signal. The signal will be completely remodulated (see Figure 4).

The encoder bitrate of the break-in signal depends on the currently lowest bitrate of all Audio sub-channels in an ensemble.

The complete Multiplex is fully replicated and replaced frame-synchronously. From the view of a DAB Radio a continuous signal is received in terms of data rate, sampling frequency, error protection, but also CIF Counter, time etc.

In this way it is guaranteed that the DAB receiver does not lose the synchronisation or even re-scans the DAB band.

In parallel, PAD data can be transmitted as Slideshow and/or as Dynamic Label so that the respective information can also be presented visually.

If a car driver listens to another medium (e.g. CD), the receiver can be switched automatically to DAB radio via an appropriate alarm signalling (if the receiver supports this feature).

The break-in trigger is in general realised via a TTL input signal, an IP SNMP command or optionally via a remote VoIP telephone call.

Beside live break-in, multiple predefined break-in signals – together with a Dynamic Label (DL) and a Slide Show (SLS) – can be stored in the system.



Figure 4: Remodulator Mode

INTRODUCTION

2 PUTTING MAGIC TBR INTO OPERATION

2.1 Mounting

With its dimensions (W \times H \times D) of 440 mm \times 44,5 mm (1 U) \times 273 mm the **MAGIC TBR** system can be used either as desktop device or mounted in 19-inch racks. Corresponding 19"mounting brackets are included in delivery.

When mounting the unit please keep in mind that the bending radius of the connected cables is always greater than the minimum allowed value.

Although **MAGIC TBR** has an integrated fan for proper cooling, it is recommended to have sufficient ventilation. The ambient temperature of the system should be within the range of +5°C and +45°C. This threshold is specially to observe if the system is inserted in a rack.



The temperature of the system can be displayed via the front panel under MENU > STATUS INFORMATION or via the System Monitor of the web interface.

During operation humidity must range between 5% and 85%.



Incorrect ambient temperature and humidity can cause functional deficiencies.

Operation outside the threshold values indicated above leads to a loss of warranty claim.

2.2 Connection to the main voltage

The system can be operated with main voltage in the range from 100 V to 220 V via the integrated redundant power supplies. The line frequency can vary from 45 Hz to 65 Hz. The maximum power consumption is not higher than 50 W if both modules are equipped.

2.3 Earthing of the system

For EMC reasons an earthing via the earthing screw on the back side of the unit must be carried out in either case.

Earthing



A lacking earthing can cause functional deficiencies within the unit. Because of the 'pending' potential, unlike the protective earth conductor potential, slight electric shocks can occur by touching the rack. These are absolutely not dangerous; however, they can be avoided totally by earthing.

2.4 Operational elements of the front keypad and display

The system has an illuminated graphical display with a resolution of 160 x 32 pixel and 19 operating buttons.

On the right next to the display there are two soft keys whose current functions are mentioned on the display. In the middle there are two cursor buttons (upwards/downwards) as well as an **OK** button. The two phone buttons for accepting/dropping have no special function except that you can display the IP address of the system by pressing the **DROP** button.

The numerical pad supports also the '*'- and '#'-key in addition to the numerical characters **0...9**. For text entries the numerical pad can also be used as a normal keypad.

Soft keys



Figure 5: Front keypad and display

2.5 Front status LEDs

MAGIC TBR has five LEDs for status indication:

- POWER green
 - System is ready for operation
- SYNC yellow blinking
 - RF input of one or both modules is not sufficient.
- ALARM red
 - At least one system alarm is pending
- INFO 1/2 yellow blinking
 - Active break-in on ensemble 1/2

2.6 Wiring of the system

To tunnel From outside slot antenna DAB antenna Analogue Audio input Digital Audio input Redundant Remote control Trigger power for via webinterface connection break-in (line level) for for live break-in live break-in Figure 6: Wiring diagram

The wiring of **MAGIC TBR** is simple as shown in Figure 6.



You can use either LAN1 or LAN2 interface (or both). If you plan to use the VoIP telephone call break-in possibility later, it is recommended to use the LAN2 interface since VoIP must run via LAN1.

2.7 Basic configuration via front panel

Although the most important functions are available via the front keypad and display the configuration with a web browser is more comfortable.

However, at least one IP address must be configured on **MAGIC TBR** directly to allow an access via a web browser:

- The standard IP address of the system is 192.168.96.102, the subnet mask is 255.255.255.0 and the standard control port 10000.
- To enable a connection with your PC, you have to be in the same subnet. Enter an IP address at your system from your subnet or activate - to get the correct settings automatically - DHCP (Dynamic Host Configuration Protocol), if a DHCP server is available.
- To change the IP address manually at the system, press the soft key Menu and then select system settings → LAN Interface →
 LAN 1 settings → IP Address (or LAN 2 Settings if you have the system connected via LAN 2 interface).
 Enter now the desired IP address. When entering manually you have to be sure that the IP address is not already used by another unit.



Maybe further settings are necessary (e.g. sub-net mask, gateway etc.). In that case please contact your network administrator, who can tell you the correct settings, or you use DHCP.

You can activate DHCP at the system via Menu \rightarrow system settings \rightarrow LAN settings \rightarrow DHCP.



You can identify the assigned or manually set IP address by pressing the **DROP** button on the front keypad. The current IP address is displayed.

3 THE WEB INTERFACE OF MAGIC TBR

After configuring the IP address of the system as described in CHAPTER 2.7, you should be able to connect with the system via your web browser.



Please note that only **two** users can access the system via the web browser simultaneously.

We recommend to use one of the following web browser:

- Firefox (version 47 or higher)
- Google Chrome (version 53 or higher)
- Safari (version 9 or higher), also on iPad or iPhone
- Internet Explorer (version 11 or higher)

After entering the IP address into the address line of your browser you should be automatically connected to MAGIC TBR as shown in Figure 7 (of course an ensemble will not be displayed if system is not fully configured).





3.1 SETTINGS - Step-by-step configuration of the system

For a standard configuration only a few settings are mandatory:

- Setup of Operation mode (see CHAPTER 3.1.1)
- Configuration of *Break-In* scenarios (see CHAPTER 3.1.2)
- Setup of the Audio Input for live Audio announcements (see CHAPTER 3.1.3)

All other settings of the system are optional and depend on the local environment. Press the *Menu* button in the left corner to display the configuration menu.

Administrator			TBRTun	nelMunich				~
🖱 Logout								
	DR Deutschla	ind			5C (178.352	MHz)		6
Settings								
Mode	RE Input			Status				
Break-In	Ki input	-41 dBm	≥50.00 dB	•				\longrightarrow
Audio Input						- 1		
Audio Output (Monitoring)	Audio	-60					0 dBFS	IESI
LAN	PAD	DLS						
VLAN								
SNMP								
System								
Administration								
Registration								
System Settings								
Restart Device								
Firmware Download								
Set Factory Settings								
File System								
System Panel								
Extras								
System Monitor								
Protocol File Viewer								
About								

Figure 8: Configuration Menu

3.1.1 Operation mode configuration

The *Mode* configuration allows you to setup the system either in *Repeater* or *Remodulator* mode:

Operation Mode	Repeater	•		
Input Frequency	5C (178.352 MHz)	•	Scan	
Output Level	0		-40 dBm	

Figure 9: Operation Mode

- In *Repeater* mode the system passes through the received signal to the RF output with a very low delay of a few µs. Only in case of a break-in the system is switched to the Remodulator mode in sync to the Null symbol as well as the CIF counter to exchange all audio sub channels.
- In *Remodulator* mode the system refreshes the received signal permanently and provides a full remodulated signal on the RF output. In case of a break-in the audio content will be replaced. This mode has a much higher delay due to the high level processing (approx. 750 ms).



We recommend to use the *Repeater* mode as default mode to minimize the influence on DAB car receivers during normal operation.

Now select the desired *Input Frequency* (5A ... 13F) of the ensemble which you want to use for break-in.

The setting **Output Level** can be used to adjust the strength of the RF output in a range of -40 dBm ... 0 dBm.



If a second module is equipped the configuration has to be repeated with the desired parameters.

Press OK to store the configuration in the system

In the main window the *Ensemble name(s)* of the selected ensemble(s) should be displayed as well as the *RF Input* signal strength and the *Quality* indicator.



For a good reception the *Quality* indicator should be higher than 40%.

Default settings		
Jingle	0:/Audio/Jingle.wav	Jingle 🛃
	Attention! Announcement	
DLS Text		
Slide Show	0:/SLS10	sls 🛃
Scenarios 🚯		
Live Fire Alarm! Accide	nt Roadworks TEST	
TTL Pin 1 TTL Pin 2 TTL Pin	3 TTL Pin 4 TEST Button	
Alias	Live	
Break-In Interval	0	sec
Scenario To Play	Jingle - Live Audio - Jingle	•
been and to thay	(
Scenario Repetition	0	
Scenario Repetition	0 Use Default Jingle	V
Scenario Repetition Jingle DLS	0 Use Default Jingle Use Default DLS Text	Y

3.1.2 Break-In configuration

Figure 10: Break-In Configuration

The system allows you to define up to four **Break-In** scenarios which can be triggered either by TTL inputs (Ensemble 1: Pin 1 ... Pin 4 respectively Ensemble 2: Pin 5 ... Pin 8 of the TTL interface, see Figure 6) or SNMP commands (see CHAPTER 3.1.9).



Scenario 1 has the highest and scenario 4 the lowest priority, respectively. In general, a break-in can be cancelled by triggering Pin 1 (Pin 5 for Ensemble 2) only with a short pulse (< 200 ms).

For test purposes a test scenario can be defined which can be triggered directly via the *Test* button of the web interface (see Figure 7).

Each scenario can consist of:

- Live Audio content (*Live Audio Announcement*) with or without pre- or postjingle
- Pre-recorded Audio content (*File Announcement*) with or without pre- or post-jingle
- Dynamic Label (DLS)

- Slideshow (SLS)
- In addition, it is possible to setup different repetitions of the Audio content.
- For all scenarios you can choose to use the default DLS and SLS or a separate one for each scenario.
- The live Audio announcement sequences are shown in Figure 11, the file based Audio announcements are shown in Figure 12.



Figure 11: Live Audio Announcement Modes







Restrictions and Recommendations for Audio, DLS and SLS files

The live Audio is recorded automatically in the system so that a playout of the last live announcement in a loop is possible. The maximum length of a live Audio recording is limited to 30 minutes.

To use pre-recorded Audio content for file announcements simple WAV files can be used. Please note that the sampling frequency must be 48 kHz. All other parameters like channels, resolution etc. will be converted automatically.

Depending on the DAB receiver it needs a few seconds until the DLS is displayed. Some receivers show a new label first when the currently displayed label is completely finished.

The maximum string length of a DLS can be 200 Bytes which can be less than 200 characters if unicode characters are used.

To reduce the time which is necessary to transmit a slideshow picture it is helpful to minimize the file size of the picture. We recommend to use PNG files with less colours. File sizes of 2 ... 3 KB with the dimensions of 320 x 240 pixel (which is a must) are perfect for a proper transmission.

Although it is possible to transmit more than one picture in a slideshow, please do not forget that the transmission rate for SLS during an announcement is limited to 1.5 ... 8 kbit/s depending on the break-in encoder bitrate. That means that a file with 3 KB needs approx. 6 seconds to be transmitted.

3.1.3 Audio Input configuration

For live Audio announcements the Audio input must be configured via the submenu *Audio Input*.

Audio Input		×
Ensemble 1 Input (Slot 1)	Analogue -	
Ensemble 2 Input (Slot 2)	Analogue -	
Level	O	6 dBu
Headroom		9 dBr
	Cancel	Аррly OK
·		

Figure 13: Audio Input Configuration



Please note that the system offers analogue or digital line inputs. A microphone input is not available.

Select first the desired Audio *Input* type (*Analogue* or *Digital*) for Ensemble 1 respectively Ensemble 2.

In case of using **Analogue** Audio you can adjust the nominal **Level** in a range of -3 ... +9 dBu as well as the **Headroom** in a range of 0 ... 15 dBr.

Audio Interface Assignment (see CHAPTER 4.3)
------------------------------	------------------

Ensemble 1:	ANALOGUE	AUDIO 1 IN
	DIGITAL	AUDIO 1 (AES1 IN LEFT)
Ensemble 2:	ANALOGUE	AUDIO 2 IN
	DIGITAL	AUDIO 1 (AES1 IN RIGHT)
		or
		AUDIO 2 (AES2 IN LEFT)

3.1.4 Audio Output (Monitoring)

If desired, it is possible to monitor the **active** break-in signals.

Audio Output (Monitoring)		×
Ensemble 1 (Slot 1)		
Output Level	Analogue •	6 dBu
	Cancel Apply	ОК

Figure 14: Audio Output Configuration

Select first the desired Audio *Output* type (analogue or digital) for Ensemble 1 respectively Ensemble 2.

In case of using *Analogue* Audio you can adjust the nominal *Level* in a range of -3 ... +9 dBu.

If *Digital* Audio is selected, the *Clock Source of Digital Output* can be configured as *Internal* or External (interface CLOCK 1, see Table 10).

Audio Interface Assignment (see CHAPTER 4.3)

Ensemble 1:	ANALOGUE	AUDIO 1 OUT
	DIGITAL	AUDIO 1 (AES1 OUT LEFT)
Ensemble 2:	ANALOGUE	AUDIO 2 OUT
	DIGITAL	AUDIO 1 (AES1 OUT RIGHT)
		or
		AUDIO 2 (AES2 OUT LEFT)

3.1.5 General settings

General		×
Display Language	English	
Front Keypad Key Tone Backlight	Permanent On	
Display Contrast System Name	E TBRTunnelMunich	10
	Cancel Apply	ОК

Figure 15: General Settings

The general settings allow you to setup the parameters for

- Display language
 - o Currently English or German
- Front Keypad Tone

 $\circ \quad \text{ On or Off } \quad$

- Backlight
 - o Permanent On
 - o Auto-switch Off
- Display Contrast
 - o Range 0 ... 15
- System Name
 - The system name is shown in the main window and can be used as DNS hostname
 - o Max. 63 characters
 - Allowed characters are: A ... Z, 0 ... 9 and The . is only allowed to separate parts of the domain name

3.1.6 LAN settings

MAGIC TBR provides two separate Ethernet interfaces LAN 1 and LAN 2 which can be used for independent IP subnets.

DHCP		
IP Address	172.20.65.10	
Subnet Mask	255.255.0.0	
Default Gateway	172.20.1.1	
LAN 2		

Figure 16: LAN Settings

For each Ethernet interface you can define an *IP Address*, the *Subnet Mask* and the *Default Gateway*.

Please ask your IT Administrator for the right settings.



If you plan to use live announcements via VoIP, please use LAN 2 as control interface. VoIP is only possible via LAN 1.



Please note that only **two** users can access the system via the web browser simultaneously.

3.1.7 VLAN settings

The VLAN feature will be available in a later release.

3.1.8 SNMP settings

For remote monitoring the system can be integrated into a Network Management System (NMS).



Up to four NMS can be addressed.

To use the function, activate the checkbox **SNMP Enabled** first.

SNMP Parameters

Under *SNMP Parameters* select the desired version *V1* or *V2C* which is supported by the NMS first.

Please ask your IT Administrator for the correct *READ*, *TRAP* and *WRITE Community* parameters as well as the *SNMP Port* (default: 161).

Under *System Description, Contact* and *System Location* you can send informative details about the installed system to the NMS.

To initialise the NMS, it is recommended to **Send All Traps At Startup** as well **After Enabling**.

To minimise the number of alarms at the NMS site the system offers a classification of all available alarms (see *Traps*) with up to four categories A ... D (e.g. Important, Not Important, Informative etc.).

For each category you can enter an *Alias* to make it clearer for the users.

IMP Enabled		
SNMP Parameters		
SNMP Version	v2c •	
Read Community	public	
Trap Community	public	
Write Community	private	
SNMP Port	161	
System Description		
Contact		
System Location		
Send All Traps At Startup		
Send Traps Immediately After Enabling	•	
Category A Alias		
Category B Alias		
Category C Alias		
Category D Alias		
NMS Parameters		
SNMP Alarm Traps		
Ensemble Alarm Traps		
System Alarm Traps		
Application Alarm Traps		

Figure 17: SNMP Parameters

NMS Parameters

Assign under *NMS Parameters* the desired *LAN* interface, the *IP Address* and the *Port* (default: 162) of each of the four possible Network Management Systems that you want to integrate into your monitoring.

	•			
SNMP Parameter	'S			
NMS Parameters				
	LAN	IP Address	Port	
NMS 1	LAN 1	▼ 172.20.75.254	162	
NMS 2	LAN 1	▼ 0.0.0.0	162	
NMS 3	LAN 1	•	162	
NMS 4	LAN 1	•	162	
SNMP Alarm Trap	05			
Ensemble Alarm	Traps			
System Alarm Tra	aps			
Application Alarn	n Traps			

Figure 18: NMS Parameters

SNMP Alarm Traps

Under SNMP Alarm Traps you can define which of the listed alarms should be used.

SNMP	×
SNMP Enabled	
SNMP Parameters	
NMS Parameters	
SNMP Alarm Traps	
Cold Start	Authentification Failure
Category A	Category B
Category C	Category D
All 🕑 🛛	
Ensemble Alarm Traps	
System Alarm Traps	
Application Alarm Traps	
Ret SNMP MIB files	Cancel Apply OK

Figure 19: SNMP Alarm Traps

Ensemble Alarm Traps

Under *Ensemble Alarm Traps* you can define which of the listed alarms should be used.

SNMP	>
SNMP Enabled	
SNMP Parameters	
NMS Parameters	
SNMP Alarm Traps	
Ensemble Alarm Traps	
☑ Ensemble 1 Break-In	C Ensemble 2 Break-In
All 🤨 🗖	
System Alarm Traps	
Application Alarm Traps	
R Get SNMP MIB files	Cancel Apply OK

Figure 20: Ensemble Alarm Traps

System Alarm Traps

System alarms occur if a hardware problem exists. Typically, there is a communication problem between the processor and the indicated hardware component (e.g. Flash EPROM).

MP Enabled			
SNMP Parameters			
NMS Parameters			
SNMP Alarm Traps			
Ensemble Alarm Traps			
System Alarm Traps			
LCA	Category A -	Overheated	Category D -
✓ Time Keeper	Category A •	Main EEPROM	Category D •
Temperature Sensor	Category B •	Display Contrast DAC	Category D +
Flash EPROM	Category B •	Audio I/O Port	Category B -
Ethernet MAC 1	Category A -	C Ethernet MAC 2	Category A -
DSP 2 Access	Category A -	SP 2 Boot	Category A -
SD Card	Category B •	Redundant Power Supply	Category C •
Slot 1: DABRF Module	Category D •	Slot 1: Access	Category C -
Slot 1: Boot	Category A 🗸	Slot 2: DABRF Module	Category C -
Slot 2: Access	Category A -	Slot 2: Boot	Category A -
AII 🖾 🗆	Set All To Category None	A B C	D
Application Alarm Traps			

Figure 21: System Alarm Traps



To make it easier for the service technician in the NMS to interpret the different alarms we recommend to use only categories (see PAGE 30, SNMP Parameters) which you can assign separately for each available system alarm.

Application Alarm Traps

Application alarms reflect a problem which is typically software-based (e.g. Audio encoder is not running) or which results from the external environment (RF Synchronisation if no antenna is connected or wrong frequency is selected).

NMP Enabled					
SNMP Parameters					
NMS Parameters					
SNMP Alarm Traps					
Ensemble Alarm Traps					
System Alarm Traps					
Application Alarm Traps					
AES/EBU Input 1	Category B	•	AES/EBU Input 2	Category B	•
Inter-DSP-Communication	Category B	•	Ensemble 1: RF Blocker	Category B	•
Ensemble 1: RF Synchronisation	Category B	•	Ensemble 1: Encoder 1	Category B	•
Ensemble 1: Encoder 2	Category B	•	Ensemble 1: Encoder 3	Category B	•
Ensemble 2: RF Blocker	Category B	•	Ensemble 2: RF Synchronisation	Category B	•
Ensemble 2: Encoder 1	Category B	•	Ensemble 2: Encoder 2	Category B	•
Ensemble 2: Encoder 3	Category B	•			
All C D	Set All To Category	None	A B C	D	

Figure 22: Application Alarm Traps



To make it easier for the service technician in the NMS to interpret the different alarms we recommend to use only categories (see PAGE 30, SNMP Parameters) which you can assign separately for each available system alarm.

3.1.9 Triggering of a Break-In via SNMP

Similar to the break-in via hardware TTL inputs a break-in is also possible via SNMP SET commands.

For each ensemble, 6 separate OIDs are available which must be set to TRUE (except cancel trigger) to activate and FALSE to deactivate a break-in.

- amtbrEnsXBrkInScn1LiveTrigger (X=1 \triangleq TTL1, X=2 \triangleq TTL5)
- amtbrEnsXBrkInScn2Trigger

•

٠

- (**X**=1 ≙ TTL2, **X**=2 ≙ TTL6)
- amtbrEnsXBrkInScn3Trigger (X=1 \triangleq TTL3, X=2 \triangleq TTL7)
- amtbrEns<mark>X</mark>BrkInScn4Trigger
- $(X=1 \triangleq TTL4, X=2 \triangleq TTL8)$
- (≙ Website TEST button)
- amtbrEnsXBrkInTestTrigger
- $(\triangleq$ Website TEST button) (\triangleq Website CANCEL button)
- amtbrEnsXBrkInCancel

where X=1 for Ensemble 1 and X=2 for Ensemble 2



The necessary *MIB* files can be downloaded via the SNMP download link directly from the system.

3.2 ADMINISTRATION of the system

3.2.1 Registration

On the tabs *Main, SD Card Module, DAB RF Module 1* and *Module 2* all relevant features of the system for identification like *Subject Number, Factory Number, Year, Hardware Version, Firmware Version* as well as the *MAC Addresses* are displayed.

Registration	×
Main	
Firmware Version Subject Number Factory Number Year Hardware Version MAC Address 1 MAC Address 2	1.310 450159 16/03/1036 2016 3.00 00-06-9B-02-1B-F7 00-06-9B-02-1B-F8
SD Card Module	
Slot 1 (DAB RF Module)	
Features	
MAGIC TBR Basic Ensemble Module Upgrade Enter Option Password	
	Cancel Apply OK

Figure 23: Registration

Under *Features* all available software upgrades are listed.



Software Upgrades

We need the serial number (*Factory Number*) of the system for an upgrade. Please read out the serial number **always** from the *Registration* since the serial number on the system label could be different.

To activate further software upgrades later please enter the password which you received from us in the *Enter Option Password* field.

3.2.2 File System

By selecting the submenu *File System,* the file directory of the system (similar to the hard disk of a PC) is displayed.



Please do not carry out any actions under *File System* unless our support asked you to. All user import/export functions can be found under the menu.

Via the *Recycle Bin* symbol the currently selected file is deleted from the system.

File Selection				×
A C R SD Card				
Name	Size	Date	Time	
A:			63.0 kB j	free
STARTUP.CFD	1.0 kB	21.11.2018	13:05:05	
Refresh				Close

Figure 24: File System

3.2.3 Firmware Download

New firmware can be downloaded free of charge from our website to provide the newest features and bug fixes.

Firmware Download	
TBR.SSW	Choose file
File Information:	Save as:
 4.0 MB (4212043 bytes) 	 C:TBR.SSW (1.5 MB)
• 22.6.2018, 11:14:14	 C:TBR1.SSX (2.5 MB)
os Valid SSW file (v2) — Firmware Version: 1.300 View Changelog
	Abort 🗙 Start 🛃 Close

Figure 25: Firmware Download

Via the submenu *Firmware Download* the firmware can be comfortably loaded to the system.

- Select the downloaded firmware file with the *Choose File* button.
 - \circ $\;$ The standard name of the firmware file is TBR.ssw.
 - After choosing the file you will see additional information like version, size etc.
- Press *Start* to initialise the firmware transfer to the system.
- After a few minutes (approx. 6 min) the update of the system is done and an automatic reset will be initiated.



During the transfer time the system is still working. The transmission will be interrupted first **after** the system reset.

Note: In case of a necessary update of the RF modules the restart process needs more time than usually.

Don't worry if something happens during a download: The web access is still possible and you can simply restart the firmware download.

3.2.4 System Panel



The *System Panel* is only for service purposes. Please enter commands only in the prompt, if our support asks you to do so.

Press the *Recycle Bin* to clean and the *X* symbol to close the System Panel.

Administrator			TBRTun	nelMunich			~
	DR Deutschl	and			5C (178.352 MHz)		6
REPEATER	RF Input	Level 41 dBm	_{SNR} ≥50.00 dB	Status		ſ	
CANCEL	Audio PAD	60 DLS				dBFS	TEST
<pre>>>> version <<< MAGIC TBR APPLICATION SOFTWARE VERSION: 1.06</pre>	29					Į	<u> </u>
FACTORY No.: 16/03/10: MAC ADDR 1: 00-06-98-0 MAC ADDR 2: 00-06-98-0	36 32-18-F7 32-18-F8						
 							> Send

Figure 26: Main Window with opened System Panel

3.2.5 Restart Device

In the unlikely case that the system shows an unexpected behaviour a reset of the system can be initiated via the submenu *Restart Device*.

Do you really want to restart the TBR device?		×
	Cancel	ОК

3.3 EXTRAS – Maintenance functions

Via the *Extras* menu maintenance functions are available.

3.3.1 System Monitor

Via the submenu *System Monitor* all important information about the status of the system is displayed.



The *System Monitor* can also be opened by pressing the *System Status* symbol in the main window.



System Monitor		×
System Alarm		
0 LCA	O Overheated	
0 Time Keeper	0 Main EEPROM	
0 Temperature Sensor	0 Display Contrast DAC	
0 Flash EPROM	0 Audio I/O Port	
0 Ethernet MAC 1	0 Ethernet MAC 2	
0 DSP 2 Access	0 DSP 2 Boot	
0 SD Card	0 Redundant Power Supply	
0 Slot 1: DABRF Module	0 Slot 1: Access	
0 Slot 1: Boot	0 Slot 2: DABRF Module	
0 Slot 2: Access	0 Slot 2: Boot	
Application Alarm		
0 AES/EBU Input 1	0 AES/EBU Input 2	
0 Inter-DSP-Communication	0 Ensemble 1: RF Blocker	
1 Ensemble 1: RF Synchronisation	0 Ensemble 1: Encoder 1	
0 Ensemble 1: Encoder 2	0 Ensemble 1: Encoder 3	
0 Ensemble 2: RF Blocker	0 Ensemble 2: RF Synchronis	ation
0 Ensemble 2: Encoder 1	0 Ensemble 2: Encoder 2	
0 Ensemble 2: Encoder 3		
System State		
Temperature 31°C	Time 21/11/2018 1	3:36:20
Load 14%	Uptime 2h 50m 20s	
Network Connections		
LANI	1482	
Dent		
TX 49.4 kBit/s	TX 0.0 kBit/s	
RX 23.3 kBit/s	RX 0.0 kBit/s	
DHCP false	DHCP false	
IP Address 172.20.65.10	IP Address 192.168.96.10)3
Subnetmask 255.255.0.0	Subnetmask 255.255.0)
Gateway 172.20.1.1	Gateway 192.168.96.1	
LAN 1 false	LAN 2 true	
LINK 100 MBIT/S TUII duplex	LINK	
Connected Clients		
1: 172.20.10.16	2: 172.20.10.1	
Last Alarm Reset: 21/11/2	018 13:34:55 Reset Alarm Counte	r Close

Figure 27: System Monitor

A **red** LED indicates a currently existing alarm, a **blue** LED means that an alarm has occurred since the last *Reset Alarm Counter*. A green LED shows that everything is running without any problems.

The *Alarm Counter* on the left side of an LED displays how often the alarm occurred since the unit has been switched on respectively the last *Reset Alarm Counter*.

In general, the available alarms are divided into *System Alarms* (hardware alarms) and *Application Alarms* which corresponds to the SNMP alarms (see CHAPTER 3.1.8).

Additional information is shown for:

- **System Temperature**: The temperature is measured in °C. A normal system temperature lies around 30°C ... 45°C
- Load: DSP Load of the system
- *Time*: The current local time which is taken from the received DAB signal of Ensemble 1
- Uptime: The time between now and the last power on or reset.
- Ethernet State: Information about the LAN 1 and LAN 2 link
- *Absolute Data Rates*: Information about the data rate of the two Ethernet interfaces for RX and TX direction
- **Connected Clients**: Information about the clients IP address which are currently accessing the system
- Last Alarm Reset: Time when the Reset Alarm Counter button was pressed

3.3.2 Protocol File Viewer

The integrated *Protocol File Viewer* shows all important events of the system.

Depending on the entry typical up to 5000 events can be stored.

Protocol File Viewer ×						
Category All	Since La	st Reset	Search:			
Start / End	Duration	Category	Ensemble	Event		
21/03/2038 07:04:55		Application		Ensemble 1: RF Blocker		
21/03/2038 07:04:18 21/03/2038 07:04:55	37s	Application		Ensemble 1: RF Synchronisation		
21/11/2018 13:35:42		Application		Ensemble 1: RF Synchronisation		
21/11/2018 13:04:52 21/11/2018 13:05:06	14s	Application		Ensemble 1: RF Synchronisation		
21/11/2018 11:35:17 21/11/2018 10:45:56	<15	System		Redundant Power Supply		
21/11/2018 11:35:10		Reset		Power Up/Reset (Release 1.301)		
21/11/2018 11:15:31 21/11/2018 10:18:58	<15	System		Redundant Power Supply		
21/11/2018 11:15:24		Reset		Power Up/Reset (Release 1.301)		
21/11/2018 11:01:31		Application		Ensemble 1: RF Synchronisation		
21/11/2018 11:01:09 21/11/2018 11:07:00	5m 51s	System		Redundant Power Supply		
21/11/2018 11:01:02		Reset		Power Up/Reset (Release 1.300)		
21/11/2018 10:59:22		Download		Firmware Download		
21/11/2018 10:58:25		Download		Firmware Download		
21/11/2018 10:56:43 21/11/2018 11:01:02	4m 18s	System		Slot 1: Boot		
21/11/2018 10:56:43		Application		AES/EBU Input 1		
21/11/2018 10:56:37		Reset		Power Up/Reset (Release 1.310)		
21/11/2018 10:56:29 21/11/2018 10:56:37	7s	System		Slot 1: DABRF Module		
21/11/2018 10:56:27 21/11/2018 10:56:27	<15	Application		Ensemble 1: RF Synchronisation		
21/11/2018 10:56:09 21/11/2018 10:56:10	<15	System		Slot 1: DABRF Module		
Showing 1 to 253 of 253 entries				Copy to Clipboard Export as CSV Export for Excel		
				Delete Protocol File Reload Protocol File Close		

Figure 28: Protocol File Viewer

Via the options *Category* and *Search* you can simply filter the log file to find certain events.

Additionally, it is possible to export the log file as **CSV** or **MS Excel** file or to copy it to the clipboard.

3.3.3 Detailed Ensemble Information

Via the **symbol** in the main window detailed information about the selected ensemble can be displayed.

The following details are available:

- Frequency
- Ensemble Label
- Ensemble ID

As graph related to the time (last 20 seconds):

- Reception Level
- Signal-to-Noise Ratio (SNR)
- Crest Factor
- Reception Quality
- Bit Error Rate (BER) of the FIC
- Bit Error Rate (BER) of the MSC



Figure 29: Detailed Ensemble Information

3.3.4 About

In the *About* dialogue, you will find the *Firmware version* of the system Furthermore, you can find our contact information especially for support requests.

430513: MAGIC TBR Version 1.310	×
Copyright © 2015-2016	
AVT Audio Video Technologies GmbH Nordostpark 91	
D-90411 Nürnberg	
Germany	
Support: +49 911 5271 160	
Internet: www.avt-nbg.de	
E-Mail: support@avt-nbg.de	
AVT Audio Video Technologies	
View Changelog	Close

Figure 30: About Dialogue

3.3.5 Login/Logout

Via submenu *Login* you will get full access to the system after entering the password which you can configure under submenu *General*.

TBR Login	×
•••••	
	Close Login ••

To secure the system against unauthorised access do not forget to *Logout* from the system or to close the web browser.



If you have forgotten the password, a reset of the password is only possible by loading the *Factory Settings* via the front keypad.

4 INTERFACES



Figure 31: Interfaces of MAGIC TBR

4.1 LAN 1/2 Interface

The LAN 1 and LAN 2 interfaces can be used as control interfaces. LAN 1 can also be used as VoIP interface. For the LAN interfaces RJ45 sockets are used. The pin assignment of the socket is shown in Table 1.

Table 1	: LAN 1/2	Interface
---------	-----------	-----------

Γ	,					L	
ľΤ	T	T	T	Ţ	T	T	T
8							1

Pin	Signal		Electrical characteristics
1	TX+	Data out +	Socket: Western 8 pin, RJ45
2	TX-	Data out -	
3	RX+	Data in +	Recommendation: IEEE 802.3/Ethernet
4	not used		Data rate (Auto neg.): 10/100 Mbit/s
5	not used		Recommended cable: CAT5 or higher
6	RX-	Data in -	Max. cable length: 100m
7	not used		
8	not used		

4.2 TTL/Relay Interface

The TTL/Relay interface is realised as a 25-pin socket. It provides 8 programmable TTL inputs or outputs and 8 relay contacts. The pin assignment of the socket is shown in Table 2.

Table	2:	TTL	/Relay	[,] Interface
-------	----	-----	--------	------------------------



Pin	Signal		Electrical characteristics
1	TTL 1	input/output	Socket (female): SUB-D 25-pin
2	TTL 2	input/output	
3	TTL 3	input/output	TTL:
4	TTL 4	input/output	Maximum voltage: 3.3 V
5	TTL 5	input/output	Maximum current: 10 mA
6	TTL 6	input/output	
7	TTL 7	input/output	Relay interface:
8	TTL 8	input/output	Maximum voltage: 48 V Maximum current: 200 mA
9	RELAY 4 (B)	output, NO	
10	RELAY 5 (B)	output, NO	
11	RELAY 6 (B)	output, NO	
12	RELAY 7 (B)	output, NO	
13	RELAY 8 (B)	output, NO	
14	RELAY 1 (A)	output, NO	
15	RELAY 1 (B)	output, NO	
16	GND		
17	RELAY 2 (A)	output, NO	
18	RELAY 2 (B)	output, NO	
19	RELAY 3 (A)	output, NO	
20	RELAY 3 (B)	output, NO	
21	RELAY 4 (A)	output, NO	
22	RELAY 5 (A)	output, NO	
23	RELAY 6 (A)	output, NO	
24	RELAY 7 (A)	output, NO	
25	RELAY 8 (A)	output, NO	

NO = Normally Open

4.3 Audio Interfaces

The Audio input interfaces can be used for live Audio announcements and the Audio output interfaces for Audio monitoring.

4.3.1 Analogue Inputs/Outputs

Table 3: Analogue Audio Input Interface



Pin	Signal		Electrical characteristics
1	GND	Ground	Socket (female): XLR 3-pin
2	A	Audio +	
3	В	Audio -	

Table 4: Analogue Audio Output Interface



Pin	Signal		Electrical characteristics
1	GND	Ground	Connector (male): XLR 3-pin
2	А	Audio +	
3	В	Audio -	

4.3.2 Phones Interface

For Audio Monitoring a standard 6.3 mm phones interface is available on the front panel.



Table 5: Phones Interface

Pin	Signal		Electrical characteristics
-	GND	Ground	Connector (male): 6.3 mm jack ¹
-	L	Audio Left	
-	R	Audio Right	

¹ Graphic source: Benedikt.Seidl, CC BY-SA 3.0, https://commons.wikimedia.org/w/index.php?curid=4173292

4.3.3 Digital AES/EBU Audio Interfaces



Pin	Signal		Electrical characteristics	
1	AES 1 IN +	AUDIO 1/2 IN	Socket (female):	
2	AES 1 IN -	b) Ensemble 1/2 (left/right)	SOB-D 12-pin	
3	AES 2 IN +	AUDIO 3/4 IN	AES/EBU (AES3) IEC 60958	
4	AES 2 IN -	b) -		
5	AES 1 OUT +	AUDIO 1/2 OUT a) Ensemble 1 (left)		
6	AES 1 OUT -	b) Ensemble 1/2 (left/right)		
7	AES 2 OUT +	AUDIO 3/4 IN		
8	AES 2 OUT -	b) -		
9	GND	Ground		
10	GND	Ground		
11	GND	Ground		
12	GND	Ground		
13	GND	Ground		
14	GND	Ground		
15	GND	Ground		

Table 6: Digital Input/Output Interfaces

4.4 RF IN/RF OUT/GPS IN

The RF Input has to be connected to the DAB outside antenna. The RF Output must be connected to the tunnel slot antenna. The GPS Input is currently not in use.

Table 7: RF IN 1/2 Interface

Р	'n	Signal		Electrical characteristics	
	1	RF IN	RF input	Socket female: SMA	
	2	GND	Ground	Input level: -70 dBm 0 dBm at 50 Ohm	

Table 8: RF OUT 1/2 Interface

|--|

Pin	Signal		Electrical characteristics
1	RF OUT	RF output	Socket female: SMA
2	GND	Ground	Output level: -40 dBm0 dBm at 50 Ohm

Table 9: GPS IN 1/2 Interface



Pin	Signal	Electrical characteristics	
1	GPS IN	GPS input	Socket female: SMA
2	GND	Ground	Input Sensitivity:
			-148 dBm at 50 Ohm

4.5 Clock 1/Clock 2 Interfaces

Clock 1 can be used as external reference clock input if the digital Audio output is used and external clock source is selected.

Clock 2 is not in use.

Table 10: Clock 1/Clock 2 Interfaces



Pin	Signal		Electrical characteristics
1	CLOCK IN/OUT	Signal	Socket: BNC
2	GND	Ground	Amplitude: 0.5 to 1.9 V ₀ p
			Impedance: 75 Ohm unbalanced

INTERFACES

5 TECHNICAL DATA

• Coding algorithms per ensemble

0	2 x DAB	EN 300401

- all bit rates and sampling frequencies
- 1 x DAB+ ETSI TS 102 563
 - all bit rates and sampling frequencies

Line Interfaces

• VoIP LAN 1

• Control Interfaces

- o LAN 1 and/or LAN 2
- Access via web browser (max. 2 user simultaneously)
- o TTL/RELAY
 - 8 x Relay
 - 8 x TTL Input/output

Audio interfaces

- Analogue Audio 1/2:
 - Electronically balanced input XLR female
 - Electronically balanced output XLR male
 - Impedance
 - Input > 25 k Ω
 - Output $< 50 \Omega$
- Digital Audio AES/EBU:
 - Format IEC-958
 - AES3 (AES/EBU) Professional
 - Electronically balanced input
 - 15-pin SUB-D female
 - Electronically balanced output
 - 15-pin SUB-D female

Impedance

• Output: 110Ω

Separate Sample Rate Converter for Inputs

• Display

- graphical resolution
 160 x 32 Pixel
- illuminated (can be switched off)
- Dimensions
 - H x W x D
 44,5 x 434 x 257 mm
- Weight

ca. 8 kg

• Additional Information

0	EMC	CISPR 32
0	Electric safety	EN 60950
0	Temperature Range	+5 °C to 45 °C
0	Relative humidity	5% is 85%

6 GENERAL

6.1 Order numbers

MAGIC TBR	804200
Ensemble Module Upgrade	804201

6.2 Scope of delivery

- MAGIC TBR
- 2 x power cable
- 4 x Self-adhesive feet
- 19" Mounting brackets
- Manual on CD or USB stick

6.3 Declaration of conformity

The declaration of conformity you will find at the end of this manual.

7 SERVICE INFORMATION

7.1 Software and Firmware Updates

On our homepage you can download software updates for free. Go to

http://www.avt-nbg.de

and select Download Software.

7.2 Support

Our support is available on working days:

Monday until Friday from (09.00h – 17.00h CET:
Phone number:	+49 911 5271-110
Email:	support@avt-nbg.de



To deal with your problem efficiently please note down the factory number of the unit as well as the software version that you use.

The factory number is visible in the software under **Administration** \rightarrow **Registration**.

If you bought the system via your local dealer, please contact him first.

7.3 Repairs

If, contrary to expectations, your unit is defective please fill in the attached *Service Request*¹ and send the unit to the following address:

AVT Audio Video Technologies GmbH - Repairs -Nordostpark 91 D-90411 Nuernberg Germany

¹ Or download from:

http://avt-nbg.de/downloads/Info/Service%20Request%20AVT.pdf

8 LIST OF FIGURES

FIGURE 1: MAGIC TBR FRONT VIEW	. 9
FIGURE 2: MAGIC TBR REAR VIEW	. 9
FIGURE 3: REPEATER MODE	10
FIGURE 4: REMODULATOR MODE	11
FIGURE 5: FRONT KEYPAD AND DISPLAY	15
FIGURE 6: WIRING DIAGRAM	16
FIGURE 7: WEB INTERFACE OF MAGIC TBR	19
FIGURE 8: CONFIGURATION MENU	20
FIGURE 9: OPERATION MODE	21
FIGURE 10: BREAK-IN CONFIGURATION	22
FIGURE 11: LIVE AUDIO ANNOUNCEMENT MODES	23
FIGURE 12: FILE ANNOUNCEMENT MODES	23
FIGURE 13: AUDIO INPUT CONFIGURATION	25
FIGURE 14: AUDIO OUTPUT CONFIGURATION	26
FIGURE 15: GENERAL SETTINGS	27
FIGURE 16: LAN SETTINGS	28
FIGURE 17: SNMP PARAMETERS	30
FIGURE 18: NMS PARAMETERS	31
FIGURE 19: SNMP ALARM TRAPS	31
FIGURE 20: ENSEMBLE ALARM TRAPS	32
FIGURE 21: SYSTEM ALARM TRAPS	33
FIGURE 22: APPLICATION ALARM TRAPS	34
FIGURE 23: REGISTRATION	37
FIGURE 24: FILE SYSTEM	38
FIGURE 25: FIRMWARE DOWNLOAD	39
FIGURE 26: MAIN WINDOW WITH OPENED SYSTEM PANEL	40
FIGURE 27: SYSTEM MONITOR	42

FIGURE 28: PROTOCOL FILE VIEWER	44
FIGURE 29: DETAILED ENSEMBLE INFORMATION	45
FIGURE 30: ABOUT DIALOGUE	46
FIGURE 31: INTERFACES OF MAGIC TBR	49

9 LIST OF TABLES

TABLE 1: LAN 1/2 INTERFACE	49
TABLE 2: TTL/RELAY INTERFACE	50
TABLE 3: ANALOGUE AUDIO INPUT INTERFACE	51
TABLE 4: ANALOGUE AUDIO OUTPUT INTERFACE	51
TABLE 5: PHONES INTERFACE	51
TABLE 6: DIGITAL INPUT/OUTPUT INTERFACES	52
TABLE 7: RF IN 1/2 INTERFACE	53
TABLE 8: RF OUT 1/2 INTERFACE	53
TABLE 9: GPS IN 1/2 INTERFACE	53
TABLE 10: CLOCK 1/CLOCK 2 INTERFACES	53

10 INDEX

Α

Access 55 Administration 59 Alarm 31, 32, 33, 34, 42, 43 Alarm Counter 42, 43

В

BER 45 Bit Error Rate 45 Break-In 1, 11, 20, 22, 35

С

Conformity 67 Conventions 7 Crest Factor 45

D

DHCP 17 DNS 27 Download 39, 59

Ε

Earthing 14 Ensemble 9, 10, 11, 21, 22, 25, 26, 35, 43, 45, 52, 57 Ethernet 28, 43, 49 Ethernet State 43 Excel 44

F

Factory Number 37 Features 37 Firmware 37, 39, 46, 59 Firmware Version 37 Front View 9

G

GPS 10,53

Н

Hardware Version 37

I

Info 59

L

LAN 17, 28, 31, 43, 49, 55 LED 42 Level 21, 25, 26, 45 Load 43 Login 46 Logout 46

Μ

MAC 37 Mask 28 MIB 30, 35

Ν

NMS 30, 31, 33, 34

Ρ

Protocol 17, 44

Q

Quality 21, 45

R

Rear View 9 Registration 37, 59 Relay 50, 55 Remodulator 10, 21 Repairs 59 Repeater 10, 21 Reset 40, 42, 43 Restart 40

S

Safety 7, 8, 67 Scenario 22 Search 44 SNMP 11, 22, 30, 31, 33, 34, 35, 42 SNR 45 Subnet 28 Support 59 System Monitor 13, 41, 42 System Temperature 43

Т

Temperature 43, 56

Test 22		W
Time 43		
TTL 11, 22, 35, 50, 55	Wiring 16	

U

Updates 59 Uptime 43 Y

Year 37

CE Conformity

Declaration of Conformity

Name des Anbieters: Supplier's name:	AVT Audio Video Technologies GmbH				
Anschrift des Anbieters: Supplier's address:	Nordostpark 91 D-90411 Nürnberg Germany				
erklärt, dass das Produkt declares, that the product					
Produktname(n): Product name(s):	MAGIC TBR	804200			
mit den Vorschriften folgender Europäischer Richtlinien übereinstimmt: conforms to the standards of the following European directives:					
Nummer/Text: Number/title:	EN 60950 A4	Gerätesicherheit Safety			
Die Übereinstimmung wird nachgewiesen durch vollständige Einhaltung folgender Normen: The conformity is evidenced by strictly meeting the following standards:					
Harmonisierte Normen: Harmonized Standards:	 CISPR 32 Radiocommunications (Short Range Devices) Standard 2014 (referencing AS/NZS 4268) Radiocommunications (Low Interference Potential Devices) Class Licence 2015 				
Ort, Datum: Place, date:	Nürnberg, 20.05.	2016			
Name(n): Name:	Wilfried Hecht				
Rechtsverbindliche Unterschrift: Legally binding signatures:	W. Cent	Ŧ			

Telefon: Phone:

+49 911 5271-0

Diese Erklärung beinhaltet keine Zusicherung von Eigenschaften. This declaration includes no warranty of properties.

Die Sicherheitshinweise der mitgelieferten Produktdokumentation sind zu beachten. The safety instructions specified in the product documentation delivered must be observed.