DAB Multiplexer

Quick Guide

Version: 1.200 (30 October 2019)

© 2019, AVT Audio Video Technologies




- Overview
 - Hardware
 - Features
- Web Interface
 - Overview
 - General Configuration
 - Ensemble Configuration
 - Service Extraction
 - Maintenance
- Software Options
 - DABMUXplus SW Upgrade
 - Cable Upgrade
 - Emergency Warning Break-In Upgrade
- Support

Content



Overview





- DAB/DAB+ Ensemble Multiplexer
 - DSP-based ensemble multiplexer
 - 19" x 1U system with integrated wide-range power supply (100 230V AC +/-10V AC)
 - RF output for the connection to an amplifier/antenna
 - RF input is not in operation
 - GPS input for the connection of a GPS antenna

Hardware - Front





LAN interface

- connection to DAB audio encoders
- Connection to DAB ensemble MUX (EDI format)
- connection to DAB transmitters (EDI format)
- Web interface
- SNMP
- 4 x LEDs
 - CLK: static red: when GPS or NTP signals faulty green flashing: when NTP ok and GPS faulty switched off: NTP and GPS are ok.

- INF: static orange: indicates an alarm without confirmation flashing orange: indicates an existing alarm switched off: no alarm
- TX: flashing yellow: indicates RF output signal or EDI output signal switched off: indicates error
- RX: flashing yellow: indicates input data signals from the DAB Encoders or EDI signals from Ensemble MUX

switched off: indicates error

Hardware - Back (1)





- B1: Press at power on for factory reset
- B2: Press at power on for boot loader start
- RST: Reset of the system
- 12 V DC/15W for plug-in power supply

Hardware - Back (2)



DAB Ensemble Multiplexer

- According to ETSI EN 300 401 Version 2.1.1
- Manual or scheduled reconfiguration
- NPAD
- Creation of service information
- Input Protocols
 - AVTMUX with Secure Streaming
 - 2 x EDI (Sub Channel Extraction)
- Output Protocols
 - EDI (ETI)
- Audio Services
 - Max. 20 audio encoders can be connected
 - Data rates: 16-kbps up to 192-kbps
 - SBR, PS

RF output

- Modulated RF signal for the connection to a power amplifier
- For one transmitter
- Synchronisation via integrated GPS receiver
- Control software
 - Web interface


Features



Web Interface



- Enter the IP address
 of the MAGIC
 DABMUX Go in a
 modern Web
 Browser which
 supports HTML5.
- The default IP address of the device is 192.168.96.102.



Web Interface




Overview



- The DASHBOARD shows the ON AIR Multiplex.
- It provides an overview of scheduled reconfigurations, the ensemble on air and its services.
- Use the Expand Icons

 (1) to show or hide details.
- Use the Edit Icons (2) to jump to the respective configuration page.




Dashboard



- The INPUT page shows the ON AIR Multiplex.
- It provides an overview of all inputs used in the ensemble currently ON AIR.
- Use the Expand Icons

 (1) to show or hide details.
- Use the Edit Icons

 (2) to jump to the respective configuration page.




Inputs



General Configuration




- The device has one physical LAN interface and provides three logical network interfaces.
- Each network interface is defined by:
 - IP ADDRESS
 - SUBNET MASK
 - GATEWAY
 - VLAN ID
- Any changes to the network configuration take effect after restarting the device.



Network



- CLOCK SOURCE
 - NTP
 - GPS
- If NTP is selected:
 NTP server IP address
 and Port
- OUTPUT BEFORE TIME SYNCHRONISATION defines the signal being output if the system clock is out of sync to the clock source:
 - OFF/MUTE
 - OFF / MUTE UNTIL TIMEOUT
 - ON (NULL TIST)
- TIME ZONE




Time



EDI Output


- Define up to two destinations.
- Enter IP address and Port of each destination (multicast or unicast IP address)
- EDI parameter



EDI Output



- RF Output
 - Frequency and level




RF Output



NPAD Inserters

 Configure the FTP access credentials to the DABMUX Go's FTP server.




NPAD Inserters



FTP Server

Setup the DABMUX
 Go's internal FTP
 server.




FTP Server



SNMP

- GENERAL: Setup the SNMP agent.
- MANAGERS: Enter up to 4 Network
 Management Systems.
- TRAPS: Enable Traps for each event individually and group events into categories.
- Download the MIB files via the GET SNMP MIB FILES button at the bottom.




SNMP



SYSTEM

 Enable redundant power supply alarm.




System



Ensemble Configuration



- Configure ensembles in the ENSEMBLES window of the MULTIPLEXER menu.
 - NEW ENSEBLE: Add an ensemble.
 - DELETE ENSEMBLE: Delete the selected ensemble.
 - ON AIR: Activate the selected ensemble.
- Ensemble Setup
 - Name: name of the ensemble
 - Long Label: Full name of the ensemble
 - Short Label: Short name of the ensemble
 - Country
 Country where the multiplexer
 is installed
 - Id ensemble Id




Ensembles



Service Setup

- Long Label: Name of the program
- Short Label: Short name of the program
- Country:
 Country where the multiplexer is installed
- Id Service Id
- PTyProgram type




Ensemble - Services



Component and Subchannel Setup


- Content:
 - DAB+ (AAC)
 - DAB (Layer II)
 - Packet Data
- Audio Codec:
 - Sampling frequency
 - Stereo or Mono
 - SBR or PS (DAB+ only)
- PAD
 - DLS: Dynamic Label
 - SLS: Slideshow
- Bitrate/ Port:
 - Bitrate of the audio codec incl. PAD
 - Protection level
 - Subchannel ID
- Main Input: source for the main input



Ensemble - Components and Subchannels




- NEW CLUSTER:
 Create a new cluster
- ADD A SWITCH by clicking the three dots at the right.
- A switch consists of
 - TYPE
 - TRIGGER INPUT
 - SUBCHANNEL
- ANNOUNCEMENT SUPPORT: Assign announcements to services.



Announcements



- Logo sizes defined by the DAB standard are:
 - 32x32 pixels
 - 112x32 pixels
 - 128x128 pixels
 - 320x240 pixels
- Files in PNG format.
- Add logos via the three dot menu on the right of each service or drag and drop the files all at once on the service.




Service Logos



NEW INPUT

INPUT SETUP

- NAME: Name of the audio codec
- TYPE: Protocol of encoder and multiplexer
 - EDI
 - AVTMUX
- CONTROL IP: IP address of the encoder.
- AUDIO PORT: Audio port of the encoder.
- CONTROL PORT: Control port of the encoder.
- MULTICAST GROUP ADDRESS: optional.




Content Inputs



NEW TRIGER INPUT

TRIGGER INPUT SETUP


- NAME: Name of the trigger.
- TYPE: Protocol
 - UECP
- NETWORK: Network interface for UECP.
- UECP PORT
- MULITCAST GROUP ADDRESS: optional.
- UECP DATA:
 - ENCODER
 - SITE
 - PSN
 - DELAY



Trigger Inputs



- NEW EVENT
- SCHEDULER EVENT SETUP:
 - TYPE
 - At a given Date and Time
 - Every Month at given Days and Time
 - Every Week at given Days and Time
 - Every Day at a given Time
 - Every Hour at a given Time
 - Never
 - DATE: Day/Month/Year
 - TIME: h/m/s
 - ENSEMBLE: Name of the ensemble to activate.




Scheduler



Service Extraction



- Click the EDIT icon to analyse an input stream.
- Enter the stream details in the INPUT TO ANALYSE window.
- After a few seconds the streams content is displayed as a diagram in the lower part of the screen.
- Click IMPORT
 ENSEMBLE to adopt the whole input stream as a new ensemble.



Service Extraction




Maintenance



• FILE


- IMPORT MUX
 CONFIG:
 Restore the
 ensemble
 configuration
 from an external
 file.
- EXPORT MUX CONFIG: Backup the ensemble configuration to an external file.



Import / Export Mux Config




- LOGS: The device logs all events in an internal log file.
- Filter the view by Categories, a subchannel or event types.
- Export the log to an Excel file or the clipboard.
- Click REFRESH to update the view.
- Logs are lost when the device restarts or is switched off.




Logs



- You may restart the device via web interface.
- You will be prompted to confirm the restart.






Restart Device




- Updating the firmware is a 3-step process:
 - SELECT FILE: Copy the file to the device
 - WRITE FILE: Writes the firmware to the permanent memory. Do not restart or switch-off the device during writing!
 - RESTART DEVICE: Click Restart device to make the device boot the new firmware.



Firmware Download



- The SYSTEM REGISTRATION shows information about:
- Hardware
- Software
- Available and installed Software Options
- Features supported by this device according to hardware and installed software options.



System Registration



The ABOUT
 screen displays
 the firmware
 version and
 contact
 information.







Software Options



Available with Software Version 1.800

- Input streams: 4 x EDI incl. Automatic service extraction.
- Output streams: 4 x EDI (ETI), simulcast.
- 4 x integrated NPAD inserters.

Coming soon:

- Automatic Encoder and Multiplexer redundancy.
- Supports Service Linking, dynamic linkage set activation.
- Integrated PAD inserter: SLS (Slideshow), DLS (Dynamic Label).
- Connection of up to 25 external Encoders (automatic redundancy).

DABMUXplus SW Upgrade



Additional operating mode for cable network providers.

Allows

- reformatting of the EDI output signal.
- Changing the protection level.
- Changing the service label.

Cable Upgrade



- Simultaneous replacement of all programs.
- DAB Alarm Announcement Signaling.
- Requires DAB+ Encoder as Emergency Audio Source.

Emergency Warning Break-In Upgrade



Support



Web: <u>www.avt-nbg.de</u>

Email: support@avt-nbg.de

Phone: +49 911 5271-110

Support

